



**Addendum to Installation Instructions For ML180UHE,
ML180DFE, ML193UHE, ML193DFE, ML196UHE & ML196DFE**

This document supersedes any similar/conflicting instructions found in this bag assembly.

Application

This furnace is designed for single stage heating and single stage cooling/heat pump application only. Although equipped with two stage ignition control, wiring on this unit is strictly configured for single stage application. Unless allowed by this document, do not change wiring connections and never cut 2 stage compressor jumper W915 on the ignition control.

Indoor Blower Speeds (Diagram Figure 1)

For heating operation, control uses indoor blower motor speed tap connected to "Low Heat" terminal on the ignition control. See table 2 for allowable heating speed taps to meet DOE requirements for Fan Energy Rating and OEM recommended temperature rise range.

Speed tap connected to "high heat" terminal is used for heating operation only if control finds indoor blower motor already running when heat is called upon. Therefore, there must always be an allowable heating motor speed tap connected to the "High Heat" terminal of the ignition control.

For Cooling/Heat Pump operation, control uses indoor blower motor speed tap connected to the "High Cool" terminal.

Indoor blower motor speed tap connected to "Low Cool" terminal is used only for continuous air. Control energizes "Low Cool" terminal for continuous air only when dip switches are appropriately set to do so (6 "OFF", & 7 "ON").

In order to meet DOE issued July 2019 indoor blower requirements to meet Fan Energy Ratings, following motor speed taps must be connected to "Low Cool" terminal located on Ignition Control. Additionally, per table 7, Dip Switch 6 located on Ignition Control must be in "OFF" and Dip Switch 7 must be in "ON" position. See table 1 for speed tap allowed for continuous air.

TABLE 1

| Units | Model | Allowed Continuous Air Speed Tap |
|----------|-------|----------------------------------|
| ML180UHE | All | Red |
| ML180DFE | All | Red |
| ML193UHE | All | Red |
| ML193DFE | All | Red |
| ML196UHE | All | Red |
| ML196DFE | All | Red |

On-Board Links and Diagnostic Push Button (Figure 2)

On-Board Link W914 Dehum - DO NOT CUT

On-board link W914, the connection between R & DS, must NOT be cut, as this furnace is strictly designed for 1 stage compressor application only and is NOT designed to operate in dehumidification mode.

On-Board Link W951 Heat Pump (R to O)

On-board link W951 is a clippable connection between terminals R and O on the integrated control. W951 must be cut when the furnace is installed in applications which include a heat pump unit and a thermostat which features dual fuel use. If the link is left intact, terminal "O" will remain energized eliminating the HEAT MODE in the heat pump.

On-Board Link W915 2 Stage Compr (Y1 to Y2)

[DO NOT CUT]

On-board link W915 is a connection between terminals Y1 and Y2 on the integrated control. W915 must NOT be cut, as this furnace is strictly designed for 1 stage compressor application.



TABLE 2

| Model No. | Allowable Heating Speed Taps (For "Low Heat" terminal at Ignition Control) | | | | |
|-----------------|--|-------------|-------------|-------------|-------------|
| | Black | Brown | Blue | Yellow | Red |
| ML180UH045E36A | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH045XE36A | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH070E36A | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH070XE36A | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH070E36B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH070XE36B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH090E48B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH090XE48B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH090E60C | Not Allowed | Allowed | Allowed | Allowed | Allowed |
| ML180UH110E60C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH110XE60C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180UH135E60D | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML193UH030XE36B | Not Allowed | Allowed | Allowed | Allowed | Allowed |
| ML193UH045XE36B | Not Allowed | Allowed | Allowed | Allowed | Allowed |
| ML193UH070XE36B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML193UH090XE36C | Not Allowed | Allowed | Allowed | Not Allowed | Not Allowed |
| ML193UH090XE48C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML193UH110XE48C | Allowed | Allowed | Allowed | Not Allowed | Not Allowed |
| ML193UH110XE60C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML193DF045XE36B | Not Allowed | Allowed | Allowed | Allowed | Allowed |
| ML193DF070XE36B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML193DF090XE48C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML196UH030XE36B | Allowed | Allowed | Allowed | Allowed | Allowed |
| ML196UH045XE36B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML196UH070XE36B | Not Allowed | Not Allowed | Allowed | Allowed | Not Allowed |
| ML196UH070XE48B | Not Allowed | Not Allowed | Not Allowed | Allowed | Allowed |
| ML196UH090XE36C | Not Allowed | Allowed | Allowed | Not Allowed | Not Allowed |
| ML196UH090XE48C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML196UH090XE60C | Not Allowed | Not Allowed | Allowed | Allowed | Not Allowed |
| ML196UH110XE60C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML196UH135XE60D | Not Allowed | Not Allowed | Allowed | Allowed | Not Allowed |
| ML196DF045XE36B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML196DF070XE48B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML196DF090XE48C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML196DF110XE60C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180DF045E36A | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180DF070E36A | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180DF070E36B | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |
| ML180DF090E48B | Not Allowed | Allowed | Allowed | Allowed | Allowed |
| ML180DF110E60C | Not Allowed | Allowed | Allowed | Allowed | Not Allowed |

Wiring Diagram ML180DFE





FIGURE 2

Integrated Ignition Control



3/16" QUICK CONNECT TERMINALS

FLAME SENSE SIGNAL
 HI COOL 24VAC - Used for normal cooling operation
 HI HEAT 24VAC - Used for 60 second heating operation if indoor blower is running during heat demand
 LO COOL 24VAC - Continuous fan see table 7
 LO HEAT 24VAC - Used for normal heat operation
 PARK
 PARK
 COMMON 24VAC

1/4" QUICK CONNECT TERMINALS

NEUTRALS = 120 VAC NEUTRAL
 HUM = UNPOWERED NORMALLY OPEN (DRY) CONTACTS
 LI = 120 VAC INPUT TO CONTROL
 ACC = 120 VAC OUTPUT TO OPTIONAL ACCESSORY

THERMOSTAT CONNECTIONS (TB1)

W1 = Heat Signal From Single Stage T-Stat
 W2 = Not Used
 Y1 = Not Used
 Y2 = Cool Signal From Single Stage T-Stat
 G = Manual Fan From T-Stat
 C = T-Stat Signal Ground Connected To Transformer Ground (TR) And Chasis Ground (GRD)
 R = Class 2 Voltage To T-Stat
 L = Not Used
 DH = Not Used
 DS = Not Used

FIGURE 3

Diagnostic LED (Figure 3)

The seven-segment diagnostic LED displays operating status, error codes and other information. Table 4 lists diagnostic LED codes.

Diagnostic Push Button (Figure 3)

The diagnostic push button is located adjacent to the seven-segment diagnostic LED. This button is used to enable the Error Code Recall “E” mode and the Flame Signal “F” mode. Press the button and hold it to cycle through a menu of options. Every five seconds a new menu item will be displayed. When the button is released, the displayed item will be selected. Once all items in the menu have been displayed, the menu resumes from the beginning until the button is released.

Error Code Recall Mode

Select “E” from the menu to access the most recent 10 error codes. Select “c” from the Error Code Recall menu to clear all error codes. Button must be pressed a second time while “c” is flashing to confirm command to delete codes. Press the button until a solid “≡” is displayed to exit the Error Code Recall mode.

Flame Signal Mode

Select “F” from the menu to access the flame signal mode. The integrated control will display the flame current on seven-segment LED in in micro amps (uA).

Flame signal mode is exited after any of the following:

- Power is reset
- Pressing and holding push button until 3 horizontal lines “≡” are displayed
- 10 minutes after entering the flame sense mode.

**TABLE 3
Integrated Control Diagnostic Modes**

| Display | Action (when button released) |
|-------------------|-------------------------------|
| No change (idle)* | Remain in idle mode |
| Solid “E” | Enter diagnostic recall mode |
| Solid “F” | Enter flame signal mode |

**TABLE 4
Integrated Diagnostic Codes / Status of Equipment**

| Code | Diagnostic Codes/Status of Equipment | Action Required to Clear and Recover |
|-------|---|---|
| . | Idle mode (Decimal blinks at 1 Hertz -- 0.5 second ON, 0.5 second OFF). | |
| C | Cooling stage (1 second ON, 0.5 second OFF) 1 or 2 displayed / Pause / Repeat codes. | |
| d | Dehumidification mode (1 second ON, 1 second OFF) / Pause / Repeat Codes). | |
| H | Gas Heat Stage (1 second ON, 0.5 second OFF) 1 or 2 displayed / Pause / Repeat codes. Blinking during ignition. | |
| h | Heat pump stage. | |
| E 110 | Low line voltage. | Line Voltage Low (Voltage lower than nameplate rating). Check power line voltage and correct. Alarm clears 5 seconds after fault recovered. |
| E 111 | Line voltage polarity reversed. | Reverse line power voltage wiring. System resumes normal operation 5 seconds after fault recovered. |
| E 112 | Ground not detected | System shuts down. Provide proper earth ground. System resumes normal operation 5 seconds after fault recovered. |
| E 113 | High line voltage. | Line Voltage High (Voltage higher than nameplate rating). Provide power voltage within proper range. System resumes normal operation 5 seconds after fault recovered. |
| E 114 | Line voltage frequency out-of-range. | No 60 Hertz Power. Check voltage and line power frequency. Correct voltage and frequency problems. System resumes normal operation 5 seconds after fault recovered. |
| E 115 | Low 24V - Control will restart if the error recovers. | 24-Volt Power Low (Range is 18 to 30 volts). Check and correct voltage. Check for additional power-robbing equipment connected to system. May require installation of larger VA transformer to be installed in furnace / air handler. Clears after fault recovered. |
| E 117 | Poor ground detected (Warning only) | Provide proper grounding for unit. Check for proper earth ground to the system. Warning only will clear 30 seconds after fault recovered. |

* No change implies the display will continue to show whatever is currently being displayed for normal operation (blinking decimal, active error code, heat state, etc..)

TABLE 4 Continued

| | | |
|-------|--|---|
| E 125 | Control failed self-check, internal error, failed hardware. Will restart if error recovers. Integrated control not communicating. Covers hardware errors (flame sense circuit faults, pin shorts, etc.). | Hardware problem on the control. Cycle power on control. Replace if problem prevents service and is persistent. Critical alert. Cleared 300 seconds after fault recovered. |
| E 200 | Hard lockout - Rollout circuit open or previously open. | Correct cause of rollout trip, or replace flame rollout switch. Test furnace operation. Cleared after fault recovered. |
| E 204 | Gas valve mis-wired. | Check gas valve operation and wiring. Clears when repaired. |
| E 205 | Gas valve control relay contact shorted. | Check wiring on control and gas valve. If wiring is correct, replace control. |
| E 207 | Hot surface ignitor sensed open | Measure resistance of hot surface ignitor. Replace if open or not within specified range found in IOM. Resumes normal operation after fault is cleared. |
| E 223 | Pressure switch failed open. | Check pressure (inches w.c.) of low pressure switch closing on heat call. Measure operating pressure (inches w.c.). Inspect vent and combustion air inducer for correct operation and restriction. Resumes normal operation after fault is cleared |
| E 224 | Pressure switch failed closed. | Check operation of low pressure switch to see if it is stuck closed on heat call longer than 150 seconds. Measure operating pressure (inches w.c.). Inspect vent and combustion air inducer for correct operation and restriction. Resumes normal operation after fault is cleared. |
| E 227 | Pressure switch open during trial for ignition or run mode. | Check pressure (inches w.c.) of low pressure switch closing on heat call. Measure operating pressure (inches w.c.). Inspect vent and combustion air inducer for correct operation and restriction. Resumes normal operation after fault is cleared. |
| E 229 | Ignition occurred with indoor blower operating | This code is information only |
| E 240 | Low flame current - Run mode. | Check micro-amperes of flame sensor using control diagnostics or field-installed mode. Clean or replace sensor. Measure voltage of neutral to ground to ensure good unit ground. Alert clears after current heat call has been completed. |
| E 241 | Flame sensed out of sequence - Flame still present. | Shut off gas. Check for gas valve leak. Replace, if necessary. Alert clears when fault is recovered. |
| E 250 | Limit switch circuit open. | Check for proper firing rate on furnace. Ensure there is no blockage in heater. Check for proper air flow. If limit not closed within 3 minutes, unit will go into 1-hour soft lockout. Resumes normal operation after fault is cleared. |

TABLE 4 Continued

| Code | Diagnostic Codes/Status of Equipment | Action Required to Clear and Recover |
|-------|--|--|
| E 270 | Soft lockout - Exceeded maximum number of retries. No flame current sensed. | Check for proper gas flow. Ensure that ignitor is lighting burner. Check flame sensor current. Clears when heat call finishes successfully. |
| E 271 | Soft lockout - Exceeded maximum number of retries. Last retry failed due to the pressure switch opening. | Check pressure (inches w.c.) of low pressure switch closing on heat call. Measure operating pressure (inches w.c.). Inspect vent and combustion air inducer for correct operation and restriction. Clears when heat call finishes successfully. |
| E 272 | Soft lockout - Exceeded maximum number of recycles. Last recycle due to the pressure switch opening. | Check operation of low pressure switch to see if it is stuck closed on heat call. Check pressure (inches w.c.) of high pressure switch closing on heat call. Measure operating pressure (inches w.c.). Inspect vent and combustion air inducer for correct operation and restriction. Clears when heat call finishes successfully. |
| E 273 | Soft lockout - Exceeded maximum number of recycles. Last recycle due to flame failure. | Check micro-amperes of flame sensor using control diagnostics or field-installed mode. Clean or replace sensor. Measure voltage of neutral to ground to ensure good unit ground. Clears when heat call finishes successfully. |
| E 274 | Soft lockout - Exceeded maximum number of recycles. Last recycle failed due to the limit circuit opening or limit remained open longer than 3 minutes. | Shut down system. 1-hour soft lockout. Check firing rate and air flow. Check for blockage. Clears when heat call finishes successfully. |
| E 275 | Soft lockout - Flame sensed out of sequence. Flame signal is gone. | Shut off gas. Check for gas valve leak. 1-hour soft lockout. Clears when flame has been proven stable. |
| E 290 | Ignitor circuit fault - Failed ignitor or triggering circuitry. | Measure resistance of hot surface ignitor. Replace if open or not within specifications. 1-hour soft lockout. Clears when flame has been proven stable. |

Integrated Control DIP Switch Settings

This special edition of ML196E, ML193E and ML180E units are equipped with a two-stage integrated control. This control manages ignition timing, heating mode fan off delays and indoor blower speeds based on selections made using the control dip switches and jumpers. The control includes an internal watchdog feature which automatically resets the ignition control when it has been locked out. After one hour of continuous thermostat demand for heat, the watchdog will break and remake thermostat demand to the furnace and automatically reset the control to relight the furnace.

Heating Operation DIP Switch Settings

Switch 1 -- Thermostat Selection --

This unit must be used with a single -stage thermostat only. Ignition control is factory set with DIP switch 1 in the "OFF" position, and must be left in "OFF" position. This allows unit to use motor speed tap connected to "Low Heat" terminal of ignition control for heating application.

Switch 2 -- Second Stage Delay

This furnace is designed for single stage heating and cooling only in a heat pump. The second stage delay DIP switch SW2 must be in the "OFF" position.

Indoor Blower Operation DIP Switch Settings

Switches 3 and 4 -- Heating Mode Blower-Off Delay --

The blower-on delay of 30 seconds is not adjustable. The blower-off delay (time that the blower operates after the heating demand has been satisfied) can be adjusted by moving switches 3 and 4 on the integrated control. The unit is shipped from the factory with a blower-off delay of 90 seconds. The blower off delay affects comfort and is adjustable to satisfy individual applications. Adjust the blower off delay to achieve a supply air temperature between 90° and 110°F at the exact moment that the blower is de-energized. Longer off delay settings provide

lower supply air temperatures; shorter settings provide higher supply air temperatures. Table 5 provides the blower off timings that will result from different switch settings.

TABLE 5
Blower Off Heating Mode Delay Switch Settings

| Blower Off Delay (Seconds) | Switch 3 | Switch 4 |
|----------------------------|----------|----------|
| 60 | On | Off |
| 90 (Factory) | Off | Off |
| 120 | Off | On |
| 180 | On | On |

Switch 5 -- Cooling Mode Blower-Off Delay-- The unit is shipped from the factory with the dip switch positioned OFF for a 45 second delay. Table 6 provides the cooling mode off delay settings.

TABLE 6
Blower Off Cooling Mode Delay Switch Settings

| Blower Off Delay (Seconds) | Switch 5 |
|----------------------------|----------|
| 45 (Factory) | Off |
| 2 | On |

Switches 6 and 7 -- Continuous Fan Mode --

Continuous fan speed can be controlled by changing DIP switch positions. Table 7 below provides DIP switch settings for continuous fan mode. See page 1 "Indoor Blower Speeds" for speed tap selection for optimum continuous fan performance.

TABLE 7
Continuous Fan Mode

| Selection For Continuous Fan | Switch 6 | Switch 7 |
|------------------------------|----------|----------|
| Low Heat Speed | OFF | OFF |
| Low Cool Speed | OFF | ON |
| High Heat Speed | ON | OFF |
| High Cool Speed | ON | ON |

INTEGRATED CONTROL CONFIGURATION GUIDE








FIGURE 4

TABLE 8
Field Wiring Applications With Conventional Single Stage Thermostat

| Thermostat | DIP Switch Settings and On-Board Links | | Wiring Connections |
|-----------------|---|--|--|
| | DIP Switch 1 Thermostat Heating Stages | On Board Links | |
| 1 Heat / 1 Cool | OFF | <p align="center">DO NOT CUT ANY ON-BOARD LINKS</p>  | <p>S1 SINGLE STAGE T'STAT FURNACE TERM. STRIP OUTDOOR UNIT</p>  |

| Thermostat | DIP Switch Settings and On-Board Links | | Wiring Connections |
|--|---|---|--|
| | DIP Switch 1 Thermostat Heating Stages | On Board Links Must Be Cut To Select System Options | |
| Dual Fuel Single Stage Heat Pump | OFF | <p>CUT ON-BOARD LINK W951 HEAT PUMP</p>  | <p>S1 SINGLE STAGE T'STAT FURNACE TERM. STRIP HEAT PUMP</p>  |

* Connect W1 to W1 ONLY if using defrost tempering kit 67M41

NOTE - Do NOT make a wire connection between the room thermostat L terminal and the L terminal of the integrated control.